

**Fronius Symo**  
**10.0-3-M / 12.5-3-M / 15.0-3-M**  
**17.5-3-M / 20.0-3-M**  
**10.0-3-M-light / 12.5-3-M-light**  
**15.0-3-M-light / 17.5-3-M-light**  
**20.0-3-M-light**  
**Fronius Symo 10.0-3-M-OS**  
**Fronius Eco**

DE

Serviceanleitung  
Ersatzteilliste  
Netzgekoppelter Wechselrichter

EN

Service manual  
Spare parts list  
Grid-connected inverter



# Contents

<b>General information</b>	<b>91</b>
Foreword and safety instructions .....	93
Safety .....	93
Protective measures against ESD .....	93
Fronius Technical Support .....	93
Ordering spare parts .....	93
General .....	93
Tools and measuring devices .....	93
Functional description .....	94
Troubleshooting guide .....	94
Replacing components .....	94
Components with their own instructions .....	94
Safety inspection .....	94
Appendix .....	94
Tools and measuring devices .....	95
General .....	95
Tools required .....	95
Measuring and testing equipment .....	95
Ancillary materials .....	95
Function overview .....	96
Device concept .....	96
Proper use/intended purpose .....	97
Warning notices on the device .....	97
Software update .....	98
<b>Error location aid</b>	<b>99</b>
Service codes .....	101
Safety .....	101
General .....	101
Displaying status codes .....	101
Software update after a PC board replacement .....	101
Total failure of the display .....	101
Status codes .....	102
Customer service .....	115
Operation in dusty environments .....	115
Error flowchart .....	116
General .....	116
Permanent faults .....	116
Temporary faults .....	117
Abnormal behaviour .....	117
<b>Changing components</b>	<b>119</b>
General .....	121
Safety .....	121
Measuring the intermediate circuit voltage .....	121
ESD guidelines .....	122
General .....	122
Overview .....	122
Changing components .....	124
Safety .....	124
Opening and closing the device .....	124
Replacing threaded bushings in the base shell .....	127
Replacing the DC disconnect .....	129
Replacing the DC disconnect Eco .....	130
Replacing the Eco fuse .....	132
Replacing the Overvoltage PC board Eco .....	133

Replacing the overvoltage PC board - Symo .....	136
Replacing the external fan .....	139
Replacing the Symo internal fan .....	142
Replacing the Eco internal fan .....	143
Replacing the Datamanager cardWLAN option .....	145
Replacing the display PC board - Recerbo .....	147
Replacing the filter PC board - SymoFIL .....	149
Replacing the filter PC board - EcoFIL .....	150
Replacing the power board - SymoPS AC .....	152
Replacing the power board - SymoPS DC .....	154
Replacing the power board - EcoPS .....	156
Replacing other components .....	158

**Safety Inspections** **159**

Safety Inspections .....	161
Safety inspection .....	161
Responsibility .....	161
Area of application .....	161
Inspection staff qualifications .....	161
Measuring instruments .....	161
Visual inspections .....	163
General .....	163
Mains supply and connecting lines .....	163
Housing and covers .....	163
Adjustment and display devices .....	163
Rating plate and warning stickers .....	163
Electrical tests .....	164
Insulation resistance .....	164
Ground conductor resistance .....	165
Ground conductor current .....	166
Contact current .....	167
Finally .....	169
General .....	169
General .....	169
Function tests .....	170
Function .....	170
Grid on/off devices .....	170
Indicators and control elements .....	170
Documentation .....	171
Documentation .....	171

**Appendix** **173**

Spare parts list: Fronius Symo .....	174
Spare parts list: Fronius Eco .....	177
Circuit diagrams: Fronius Symo .....	178
Circuit diagrams: Fronius Eco .....	179

# **General information**

# Foreword and safety instructions

---

## Safety



**WARNING!** Work that is carried out incorrectly can cause serious injury and damage. All activities described in the service manual must only be carried out by Fronius-trained service technicians. Take note of the "Safety rules" section in the inverter operating instructions.



**WARNING!** An electric shock can be fatal. Before opening the device:

- Move the mains switch to the O position
- Unplug the device from the mains
- Put up an easy-to-understand warning sign to stop anybody inadvertently switching it back on again
- Using a suitable measuring instrument, check to make sure that electrically charged components (e.g. capacitors) have been discharged.



**WARNING!** An electric shock can be fatal. If the device needs to be switched on briefly for testing while the housing is open:

- Do not touch any parts inside the housing
- Only touch using suitable measuring or test probes



**WARNING!** An inadequate ground conductor connection can cause serious injury or damage. The housing screws provide a suitable ground conductor connection for earthing (grounding) the housing and must NOT be replaced by any other screws which do not provide a reliable ground conductor connection.

---

## Protective measures against ESD

Danger of damage to electrical components from electrical discharge. Suitable measures should be taken to protect against ESD when replacing and installing components.

---

## Fronius Technical Support

Please contact your national Fronius Technical Support team with any fault analysis queries.

---

## Ordering spare parts

Please contact your national Fronius Technical Support team to order spare parts or to consult on fault analysis queries.

---

## General

The service manual can be obtained from the DownloadCenter at "[downloadcenter.fronius.com](https://downloadcenter.fronius.com)".

Each chapter in the service manual deals with one complete topic. Use each chapter as a self-contained source of information. A short description of each chapter follows.

---

## Tools and measuring devices

This provides an overview and description of all equipment required for servicing the device professionally. This equipment includes:

- Tools required
- Measuring and testing equipment
- Ancillary materials

---

**Functional de-  
scription**

Contains a brief descriptive overview of the entire system.

---

**Troubleshooting  
guide**

Used to systematically locate and rectify errors.

---

**Replacing com-  
ponents**

The "Replacing components" chapter describes how to replace components that

- have no instructions of their own for replacement and
- require detailed replacement instructions

---

**Components with  
their own instruc-  
tions**

The following components have their own Installation Instructions

- State 112 KIT (42,0410,2321)

---

**Safety inspection**

This section outlines the safety inspection for the device described in this service manual.

Please be aware of the requirements and standards relevant to your country, as the measured values or steps taken during the tests may vary.

Even if there are no relevant requirements and standards in your country, Fronius recommends that this inspection should still be carried out.

The safety inspection must only be carried out on a fully assembled device.

---

**Appendix**

The Appendix contains the complete spare parts list and circuit diagram for the device. The circuit diagram is also supplied with the device.

# Tools and measuring devices

---

**General** "Tools and measuring devices" offers an overview and description of all equipment needed to service the device professionally. This equipment includes:

- Tools required
  - Measuring and testing equipment
  - Ancillary materials
- 


- Tools required**
- Torx screwdriver, TX20
  - Torx screwdriver, TX25
  - Slotted screwdriver, 3 mm
  - Socket wrench
  - Socket wrench insert, 7 mm
  - Socket wrench insert, 36 mm
  - Flat spanner, 7 mm
  - Flat spanner, 36 mm
  - Diagonal cutting pliers
  - Needle-nosed pliers
  - Torque screwdriver with bit insert, 1 - 6 Nm
  - Torque ratchet, 1 - 10 Nm
  - Allen key, 4 mm
  - Allen key, 5 mm
- 

- Measuring and testing equipment**
- Digital multimeter
  - Safety inspection equipment
- 

- Ancillary materials**
- Cleaning materials (spray, paper)
  - Cable tie types 102 and 200
  - Heat conductive foil, TPC (42,0300,3054)

# Function overview

## Device concept



## Device design:

- (1) Housing lid
- (2) Inverter
- (3) Wall bracket
- (4) Connection area incl. DC main switch
- (5) Data communication area
- (6) Data communication cover

The inverter converts the direct current created in the solar modules into alternating current. This alternating current is fed into the public grid synchronously with the grid voltage.

The inverter has been developed exclusively for use in grid-connected photovoltaic systems; it is impossible to generate energy independently of the public grid.

Thanks to its design and the way it works, the inverter is extremely safe both to install and to operate.

The inverter automatically monitors the public grid. In the event of abnormal grid conditions, the inverter ceases operating immediately and stops feeding power into the grid (e.g. if the grid is switched off, if there is an interruption, etc.). Grid monitoring involves monitoring voltage, frequency and the stand-alone situation.

The inverter operates fully automatically. As soon after sunrise as there is sufficient energy available from the solar modules, the inverter starts monitoring the grid. When insolation has reached a sufficient level, the inverter starts feeding energy into the grid. The inverter operates in such a way that the maximum possible amount of power is obtained from the solar modules.

As soon as the power available has fallen below the level at which energy can be fed into the grid, the inverter disconnects the power electronics completely from the grid and stops running. It retains all its settings and stored data.

If the inverter becomes too hot, it automatically reduces the current output power in order to protect itself.

Reasons for the inverter becoming too hot include the ambient temperature being too high or inadequate heat dissipation (e.g. if it is installed in a switch cabinet without suitable heat dissipation).

The Fronius Eco does not have an internal boost converter. This results in certain restrictions in the choice of solar module and string. The minimum DC input voltage ( $U_{DC \min}$ ) depends on the grid voltage. On the other hand, a highly optimised device is then available for the appropriate application.

**Proper use/intended purpose**

The inverter is intended exclusively to convert direct current from solar modules into alternating current and to feed this into the public grid.

Utilisation not in accordance with the intended purpose comprises:

- Any use above and beyond this purpose
- Making any modifications to the inverter that have not been expressly approved by Fronius
- the installation of components that are not distributed or expressly approved by Fronius.

Fronius shall not be liable for any damage resulting from such action.  
No warranty claims will be entertained.

Proper use also includes:

- Carefully reading and obeying all the instructions and all the safety and danger notices in the Operating Instructions and Installation Instructions
- Performing all stipulated maintenance work
- Installation as specified in the Installation Instructions

When designing the photovoltaic system, ensure that all components are operated within their permitted operating ranges at all times.

Observe all the measures recommended by the solar module manufacturer to ensure that the solar module retains its properties in the long term.

Obey the regulations of the power supply company regarding connection methods and energy fed into the grid.

**Warning notices on the device**

There are warning notices and safety symbols on and in the inverter. These warning notices and safety symbols must not be removed or painted over. They warn against incorrect operation, as this may result in serious injury and damage.



**Safety symbols:**

-  Risk of serious injury and damage due to incorrect operation
-  Do not use the functions described here until you have fully read and understood the following documents:
  - these operating instructions
  - all the operating instructions for the system components of the photovoltaic system, especially the safety rules
-  Dangerous electrical voltage
-  Wait for the capacitors to discharge.

**Text of the warning notices:**

**WARNING!**  
**Risk of electric shock!**  
**Non-insulated inverter**

Do not remove the cover. The device does not contain any user-serviceable parts. Servicing work must be carried out by a trained service technician.  
Both AC and DC voltage sources terminate inside this device. Each circuit must be turned

off before carrying out maintenance work.

If the solar module is exposed to light, it will supply a DC voltage to the device.

Risk of electric shock due to energy stored in capacitors. Do not remove the cover until all power supply sources have been switched off for at least 5 minutes.

**Ungrounded system:** The DC cables in this PV system are not grounded and can be live.

---

### **Software update**

With the help of the USB stick, end customers can also update the inverter software via the USB item on the SETUP menu: the update file is first saved to the USB stick, from where it is then transferred to the inverter. The update file must be saved in the root directory on the USB stick.

# **Error location aid**

# Service codes

---

## Safety



**WARNING!** An electric shock can be fatal. Before opening the device:

- If applicable, turn the mains switch to the -O- position
- Unplug the device from the mains
- Disconnect the inverter from the DC side
- Using a suitable measuring instrument, ensure that electrically charged parts (e.g. capacitors) are fully discharged
- Restrict access to the working area
- Take steps to ensure the metallic surfaces of the device cannot be touched
- Suitable protective clothing and equipment must be worn when carrying out the test or the repair

---

## General

These service codes help to localise and - where possible - rectify faults with the device directly on site. The individual service codes are subdivided into service classes.

The following information is given for every service code:

- the reason the service code is being displayed
- the relevant troubleshooting measure

**IMPORTANT!** Software may only be updated after consulting the Solar Electronics hotline. The need for the update will be clarified in advance depending on the serial number and firmware version.

---

## Displaying status codes

The inverter performs a system self diagnosis that automatically detects many faults that may occur and shows them on the display. This means you are promptly made aware of malfunctions in the inverter and the photovoltaic system, or of any installation or operating faults.

If the system self diagnosis has detected a specific fault, the associated status code will be shown on the display.

**IMPORTANT!** Status codes may sometimes appear briefly as a result of the inverter's control response. If the inverter then continues working with no sign of any problem, this means that there was no fault.

---

## Software update after a PC board replacement

In rare cases, an incompatibility message „State 480“ may occur on the inverter after the PC board has been successfully replaced.

Please carry out a software update or contact Fronius Technical Support National.

---

## Total failure of the display

If the display fails to come on some time after sunrise:

- Check the AC voltage ON the inverter connections: the AC voltage must be 230 V (+ 10 % / - 5 %)\*
- Carrying out an AC reset: Disconnect the inverter when not under load from the AC supply and switch it back on

\* The mains voltage tolerance depends on the country setup

**Status codes****Service class 1**

Status codes of these class only arise momentarily and are caused by the public grid.

The initial response of the inverter in this case is to disconnect itself from the grid. The grid is subsequently checked for the stipulated monitoring period. If no further problem has been detected by the end of this period, then the inverter will resume feeding energy into the grid.

<b>Code</b>	<b>Description</b>	<b>Behaviour</b>	<b>Remedy</b>
102	Grid voltage above permitted limit	<ol style="list-style-type: none"> <li>1. Mains voltage error</li> <li>2. Incorrect values in the Service Menu / Wrong Setup</li> <li>3. Measuring error on the filter board</li> </ol>	<ol style="list-style-type: none"> <li>1. Check mains voltage</li> <li>2. Check values in the Service Menu / Check Setup</li> <li>3. Change filter board</li> </ol>
103	Grid voltage below permitted limit	<ol style="list-style-type: none"> <li>1. Mains voltage error</li> <li>2. Wrong AC cabling</li> <li>3. Incorrect values in the Service Menu / Wrong Setup</li> <li>4. Bad contact: wall bracket &lt;-&gt; filter board</li> <li>5. Measuring error on the filter board</li> </ol>	<ol style="list-style-type: none"> <li>1. Check mains voltage</li> <li>2. Check AC cabling</li> <li>3. Check values in the Service Menu / Check Setup</li> <li>4. Check AC wall bracket screws</li> <li>5. Change filter board</li> </ol>
105	Mains frequency above permitted limit	<ol style="list-style-type: none"> <li>1. Mains voltage error</li> <li>2. Incorrect values in the Service Menu / Wrong Setup</li> <li>3. Reconnection limit</li> <li>4. Ripple control signals</li> <li>5. Measuring error on the filter board</li> </ol>	<ol style="list-style-type: none"> <li>1. Check mains voltage</li> <li>2. Check values in the Service Menu / Check Setup</li> <li>3. Normal legal requirement, no error (50,05Hz)</li> <li>4. Report to TSI specialist</li> <li>5. Change filter board</li> </ol>
106	Mains frequency below permitted limit	<ol style="list-style-type: none"> <li>1. Mains voltage error</li> <li>2. Incorrect values in the Service Menu / Wrong Setup</li> <li>3. Ripple control signals</li> <li>4. Measuring error on the filter board</li> </ol>	<ol style="list-style-type: none"> <li>1. Check mains voltage</li> <li>2. Check values in the Service Menu / Check Setup</li> <li>3. Report to TSI specialist</li> <li>4. Change filter board</li> </ol>
107	Synchronisation with the public mains supply not possible	<ol style="list-style-type: none"> <li>1. Incorrect values in the Service Menu / Wrong Setup</li> <li>2. Bad contact of the power stage set with AC</li> <li>3. Bad AC connection</li> <li>4. Measuring error on the filter board</li> </ol>	<ol style="list-style-type: none"> <li>1. Check values in the Service Menu / Check Setup</li> <li>2. Check AC connector screws</li> <li>3. Check mains connection</li> <li>4. Change filter board</li> </ol>

Code	Description	Behaviour	Remedy
108	Islanding detected	1. Islanding detected 2. Severe disturbances in public mains 3. Bad contact: wall bracket <-> filter board 4. Grid Impedance out of permitted values 5. Bad AC connection 6. Ripple control signals 7. Measuring error on the filter board	1. Automatic correction 2. Automatic correction 3. Check AC wall bracket screws 4. Contact utility 5. Check AC connection 6. Report to TSI specialist 7. Change filter board
112	RCMU Error	1. Old filter board software (<4.6) 2. Permanent grounding error	1. Software update 2. Check AC / DC connections

### Service class 2

Code	Description	Behaviour	Remedy
240	AFCI tripping	No error, AFCI tripped. Error visible for 4 Seconds then 241	Automatic correction
241 - 242	AFCI tripping	Arc occurred, to resume operation press enter twice (first 242 then operation is resumed)	Check PV generator
245	AFCI selftest fail	1. Selftest routine failed due to detection failure	1. Restart inverter or do a software update 2. Change filter board
247	AFCI currentsensor fail	1. Data from primary and secondary current sensor don't correspond	1. Restart inverter or do a software update 2. Change filter board

### Service class 3

Class 3 includes status codes that may occur while feeding energy into the grid, but generally do not cause the process to be interrupted for any length of time

The inverter disconnects automatically from the grid, the grid is then monitored as specified and the inverter attempts to resume feeding energy into the grid.

Code	Description	Behaviour	Remedy
301	Current peak on the mains supply detected	1. Voltage drop on the public mains 2. Grid Impedance out of permitted values 3. Bad contact: wall bracket <-> inverter 4. Measuring error on the filter board 5. Wrong power limit on device	1. Automatic correction 2. Contact utility 3. Check AC wall bracket screws 4. Change filter board 5. Change AC board

<b>Code</b>	<b>Description</b>	<b>Behaviour</b>	<b>Remedy</b>
302	Current peak on the PV generator	<ol style="list-style-type: none"> <li>1. Bad contact: wall bracket &lt;-&gt; inverter</li> <li>2. Voltage drop in the public mains</li> <li>3. Measuring error on the power stage set</li> </ol>	<ol style="list-style-type: none"> <li>1. Check AC wall bracket screws</li> <li>2. Automatic correction</li> <li>3. Change DC board. Afterwards if necessary AC board</li> </ol>
303	Too high heat sink temperature	<ol style="list-style-type: none"> <li>1. Ventilation opening blocked</li> <li>2. Too high ambient temperature</li> <li>3. In- or outside fan cable not connected</li> <li>4. In- or outside fan defective</li> <li>5. Bad contact: wall bracket &lt;-&gt; heat sink</li> <li>6. Measuring error on the power stage set</li> <li>7. Fan output on Recerbo defective</li> </ol>	<ol style="list-style-type: none"> <li>1. Clean openings</li> <li>2. Change mounting place</li> <li>3. Connect fan cable</li> <li>4. Change fan</li> <li>5. Check phase change paste</li> <li>6. Change AC board</li> <li>7. Change Recerbo</li> </ol>
306	POWER LOW	<ol style="list-style-type: none"> <li>1. DC power is too low for feeding in</li> <li>2. Measuring error on the power stage set</li> </ol>	<ol style="list-style-type: none"> <li>1. Wait for more irradiance or check PV modules</li> <li>2. Change DC board. Afterwards if necessary AC board</li> </ol>
307	DC LOW	<ol style="list-style-type: none"> <li>1. DC main switch open</li> <li>2. PV generator not connected</li> <li>3. DC voltage too low for feeding in</li> <li>4. Reversal voltage of PV generator</li> <li>5. DC operation mode: fix voltage + wrong voltage</li> <li>6. Measuring error on the power stage set</li> </ol>	<ol style="list-style-type: none"> <li>1. Close DC main switch</li> <li>2. Connect PV generator</li> <li>3. Wait for more irradiance or check PV modules</li> <li>4. Reverse polarity of PV generator</li> <li>5. Check MPP settings / voltage</li> <li>6. Change DC board. Afterwards if necessary AC board</li> </ol>
308	The intermediate circuit voltage	<ol style="list-style-type: none"> <li>1. Voltage drop on AC grid</li> <li>2. Bad contact: wall bracket &lt;-&gt; inverter</li> <li>3. Measuring error on the power stage set</li> </ol>	<ol style="list-style-type: none"> <li>1. Automatic correction</li> <li>2. Check AC wall bracket screws</li> <li>3. Change AC board</li> </ol>
309	Too high DC1 voltage	<ol style="list-style-type: none"> <li>1. PV generator voltage too high in MPP1</li> <li>2. Wrong DC cabling in MPP 1</li> <li>3. Measuring error on the power stage set</li> </ol>	<ol style="list-style-type: none"> <li>1. Check PV configuration</li> <li>2. Check DC cabling</li> <li>3. Change DC board. Afterwards if necessary AC board</li> </ol>
313	Too high DC2 voltage	<ol style="list-style-type: none"> <li>1. PV generator voltage too high in MPP 2</li> <li>2. Wrong DC cabling in MPP 2</li> <li>3. Measuring error on the power stage set</li> </ol>	<ol style="list-style-type: none"> <li>1. Check PV configuration</li> <li>2. Check DC cabling</li> <li>3. Change DC board. Afterwards if necessary AC board</li> </ol>

## Service class 4

Some of the class 4 status codes necessitate intervention by a Fronius-trained service engineer.

Code	Description	Behaviour	Remedy
401	Communication error between Recerbo and power stage set	<ol style="list-style-type: none"> <li>1. Ribbon cable between power stage set and filter board faulty or not connected properly</li> <li>2. Ribbon cable defective</li> <li>3. Recerbo not plugged in correctly</li> <li>4. Recerbo defective</li> <li>5. Power stage set defective</li> <li>6. Filter board defective</li> </ol>	<ol style="list-style-type: none"> <li>1. Check ribbon cable between Recerbo and power stage set</li> <li>2. Change ribbon cable</li> <li>3. Check Recerbo plug</li> <li>4. Change Recerbo</li> <li>5. Change AC board</li> <li>6. Change filter board</li> </ol>
406	Temperature sensor in DC semiconductor module defective	<ol style="list-style-type: none"> <li>1. Defective temperature sensor in semiconductor module</li> <li>2. Defective circuit on the power stage set</li> </ol>	<ol style="list-style-type: none"> <li>1. Change DC board</li> <li>2. Change DC board</li> </ol>
407	Temperature sensor on the power stage set	<ol style="list-style-type: none"> <li>1. Defective temperature sensor on the power stage set</li> <li>2. Defective circuit on the power stage set</li> </ol>	<ol style="list-style-type: none"> <li>1. Change AC board</li> <li>2. Change AC board</li> </ol>
408	On the inverter an unacceptably high DC injection was detected	<ol style="list-style-type: none"> <li>1. Asynchronous AC grid</li> <li>2. Power stage set defective</li> </ol>	<ol style="list-style-type: none"> <li>1. Check AC grid</li> <li>2. Change AC board</li> </ol>
412	Adjusted fix voltage beyond the accessible MPP range	<ol style="list-style-type: none"> <li>1. Fix voltage was adjustable too high or too low</li> </ol>	<ol style="list-style-type: none"> <li>1. Check adjustments in the service menu</li> </ol>
415	Wire shutdown tripped	<ol style="list-style-type: none"> <li>1. Option card tripped a wired shutdown</li> </ol>	<ol style="list-style-type: none"> <li>1. Automatically corrected, option card stopped the inverter</li> </ol>
416 - 425	Communication error between power stage set and Recerbo	<ol style="list-style-type: none"> <li>1. Occurs once - PSP communication error</li> <li>2. Unknown option card blocks the inverter</li> <li>3. Ribbon cable between filter and power stage set defective</li> <li>4. Recerbo defective</li> <li>5. Filter board defective</li> <li>6. Power stage set defective</li> </ol>	<ol style="list-style-type: none"> <li>1. Automatically corrected</li> <li>2. Software update</li> <li>3. Change ribbon cable</li> <li>4. Change Recerbo</li> <li>5. Change filter board</li> <li>6. Change AC board</li> </ol>
426	Charging intermediate circuit takes too long	<ol style="list-style-type: none"> <li>1. Too less DC Power</li> <li>2. DC inductors not properly connected</li> <li>3. DC booster defect</li> </ol>	<ol style="list-style-type: none"> <li>1. Restart inverter or do a software update</li> <li>2. Check DC inductors screws</li> <li>3. Change DC board. Afterwards if necessary AC board</li> </ol>
427		<ol style="list-style-type: none"> <li>1. Software error</li> <li>2. Measuring error on the power set</li> </ol>	<ol style="list-style-type: none"> <li>1. Update software</li> <li>2. Change AC board</li> </ol>



<b>Code</b>	<b>Description</b>	<b>Behaviour</b>	<b>Remedy</b>
431	Power stage set is in boot mode	<ol style="list-style-type: none"> <li>1. Power stage set will be programmed by the Recerbo automatically</li> <li>2. Power stage set can not be programmed automatically</li> <li>3. Filter board defective</li> <li>4. Recerbo defective</li> <li>5. Power stage set defective</li> </ol>	<ol style="list-style-type: none"> <li>1. Automatically corrected</li> <li>2. Software update</li> <li>3. Change Recerbo</li> <li>4. Change filter board</li> <li>5. Change AC board</li> </ol>
432	Consistent error in power stage set management	<ol style="list-style-type: none"> <li>1. Power stage set could not communicate with the Recerbo</li> <li>2. Power stage set defective</li> <li>3. Recerbo defective</li> </ol>	<ol style="list-style-type: none"> <li>1. Restart inverter or do a software update</li> <li>2. Change AC board</li> <li>3. Change Recerbo</li> </ol>
433	Allocation error of dynamic addresses	<ol style="list-style-type: none"> <li>1. Power stage set could not communicate with the Recerbo</li> <li>2. Power stage set defective</li> <li>3. Recerbo defective</li> </ol>	<ol style="list-style-type: none"> <li>1. Restart inverter or do a software update</li> <li>2. Change AC board</li> <li>3. Change Recerbo</li> </ol>
436	Problem while error transmitting of the power stage set	<ol style="list-style-type: none"> <li>1. Power stage set could not communicate with the Recerbo</li> <li>2. Power stage set defective</li> <li>3. Recerbo defective</li> </ol>	<ol style="list-style-type: none"> <li>1. Restart inverter or do a software update</li> <li>2. Change AC board</li> <li>3. Change Recerbo</li> </ol>
437	Problem with the internal error handling	<ol style="list-style-type: none"> <li>1. Power stage set could not communicate with the Recerbo</li> <li>2. Power stage set defective</li> <li>3. Recerbo defective</li> </ol>	<ol style="list-style-type: none"> <li>1. Restart inverter or do a software update</li> <li>2. Change AC board</li> <li>3. Change Recerbo</li> </ol>
438	Problem while error transmitting from power stage set to Recerbo	<ol style="list-style-type: none"> <li>1. Power stage set could not communicate with the Recerbo</li> <li>2. Power stage set defective</li> <li>3. Recerbo defective</li> </ol>	<ol style="list-style-type: none"> <li>1. Restart inverter or do a software update</li> <li>2. Change AC board</li> <li>3. Change Recerbo</li> </ol>
445	Country setup information faulty	<ol style="list-style-type: none"> <li>1. Country setup information faulty</li> <li>2. Old software (e.g after print exchange)</li> <li>3. Impossible manual settings in service menu</li> <li>4. Recerbo defective</li> </ol>	<ol style="list-style-type: none"> <li>1. Do a software update and reload country setup from setup menu</li> <li>2. Do a software update and reload country setup from setup menu</li> <li>3. Check settings</li> <li>4. Change Recerbo</li> </ol>
447	Isolation failure detected	<ol style="list-style-type: none"> <li>1. PV generator grounded</li> <li>2. PV generator grounding error</li> <li>3. Measuring circuit on power stack defect</li> </ol>	<ol style="list-style-type: none"> <li>1. Use only ungrounded modules</li> <li>2. Check PV generator</li> <li>3. Change DC board. Afterwards if necessary AC board</li> </ol>
448	Neutral wire fault	<ol style="list-style-type: none"> <li>1. No neutral wire detected</li> <li>2. Wrong setup</li> <li>3. Bad contact: wall bracket &lt;-&gt; inverter</li> <li>4. Filter board defective</li> </ol>	<ol style="list-style-type: none"> <li>1. Check wiring</li> <li>2. Check country setup</li> <li>3. Check AC wall bracket screws</li> <li>4. Change filter board</li> </ol>

Code	Description	Behaviour	Remedy
451	Flash of the guard defective	<ol style="list-style-type: none"> <li>1. Grid problem</li> <li>2. Defective AC guard on filter board</li> <li>3. Defective AC guard on power stage set</li> </ol>	<ol style="list-style-type: none"> <li>1. Automatically corrected</li> <li>2. Change filter board</li> <li>3. Change AC board</li> </ol>
452	Communication between filter & power stage set faulty	<ol style="list-style-type: none"> <li>1. Communication problem caused by temporary environmental disturbances (grid, EMC, ...)</li> <li>2. Ribbon cable between filter board and power stage set defective</li> <li>3. Defective AC guard on filter board</li> <li>4. Defective AC guard on power stage set</li> </ol>	<ol style="list-style-type: none"> <li>1. Automatically corrected</li> <li>2. Change ribbon cable</li> <li>3. Change filter board</li> <li>4. Change AC board</li> </ol>
453	Processor guard detected a faulty grid voltage	<ol style="list-style-type: none"> <li>1. Measuring error</li> <li>2. Grid problem</li> <li>3. Defective AC guard on filter board</li> <li>4. Defective AC guard on power stage set</li> </ol>	<ol style="list-style-type: none"> <li>1. Software update</li> <li>2. Automatically corrected</li> <li>3. Change filter board</li> <li>4. Change AC board</li> </ol>
454	Processor guard detected a faulty grid frequency	<ol style="list-style-type: none"> <li>1. Measuring error</li> <li>2. Grid problem</li> <li>3. Defective AC guard on filter board</li> <li>4. Defective AC guard on power stage set</li> </ol>	<ol style="list-style-type: none"> <li>1. Software update</li> <li>2. Automatically corrected</li> <li>3. Change filter board</li> <li>4. Change AC board</li> </ol>
456	Error in the Anti Islanding monitoring detected	<ol style="list-style-type: none"> <li>1. Occurs once</li> <li>2. Software problem</li> <li>3. Measuring on filter board</li> <li>4. Measuring circuit for Anti Islanding defective</li> </ol>	<ol style="list-style-type: none"> <li>1. Restart inverter</li> <li>2. Software update</li> <li>3. Change filter board</li> <li>4. Change AC board</li> </ol>
457	Grid relays do not release	<ol style="list-style-type: none"> <li>1. Occurs once</li> <li>2. Grid test time is too low</li> <li>3. Relay got stuck</li> </ol>	<ol style="list-style-type: none"> <li>1. Restart inverter</li> <li>2. Change settings</li> <li>3. Change AC board</li> </ol>
458	RCMU selftest failed	<ol style="list-style-type: none"> <li>1. RCMU measurement defect</li> </ol>	<ol style="list-style-type: none"> <li>1. Change filter board</li> </ol>
459	Faulty isolation measurement	<ol style="list-style-type: none"> <li>1. Occurs once</li> <li>2. Isolation measuring defective</li> </ol>	<ol style="list-style-type: none"> <li>1. Restart inverter</li> <li>2. Change DC board. Afterwards if necessary AC board</li> </ol>
460	Reference voltage outside permitted limits	<ol style="list-style-type: none"> <li>1. Occurs once</li> <li>2. Measuring circuit on power stage set defective</li> </ol>	<ol style="list-style-type: none"> <li>1. Restart inverter</li> <li>2. Change AC board</li> </ol>
461	Defective data memory	<ol style="list-style-type: none"> <li>1. Defective power stage set</li> </ol>	<ol style="list-style-type: none"> <li>1. Change DC board. Afterwards if necessary AC board</li> </ol>
462	Failure on the DC injection monitoring detected	<ol style="list-style-type: none"> <li>1. Occurs once</li> <li>2. DC injection monitoring defective</li> </ol>	<ol style="list-style-type: none"> <li>1. Restart inverter</li> <li>2. Change inverter</li> </ol>

<b>Code</b>	<b>Description</b>	<b>Behaviour</b>	<b>Remedy</b>
463	AC pole reserved	1. AC connector between power stage and filter board mounted in wrong direction (L1 and L2 exchanged)	1. Check wiring
472	defective grounding fuse	1. Defective grounding fuse 2. Wrong settings in service menu basic	1. Change grounding fuse 2. Set DC mode to ,floating'
474	RCMU sensor error	1. Quick radiation changes 2. Sensor defect	1. Automatically corrected 2. Change filter board
475	Isolation failure detected	1. Wrong setting 2. PV generator grounding error 3. Measuring circuit in power stage set defective	1. Check ISO / GFDI setting 2. Check PV generator 3. Change DC board. Afterwards if necessary AC board
476	Internal power supply missing	1. Grid voltage too low 2. Grid test time is too low 3. Defective internal power supply 4. Defective internal power supply	1. Check wiring 2. Grid failure 3. Change AC board 4. Change filter board
480	Power stage set software incompatible to display software	1. Old power stage set software 2. Old software 3. Incompatible hardware combinations	1. Software update 2. Reload setup 3. Check hardware components
481	Recerbo has old software version	1. Old Recerbo software 2. Old software 3. Incompatible hardware combinations	1. Software update 2. Reload setup 3. Check hardware components
482	Inverter switched off during commissioning	1. Startup procedure not successful	1. Restart inverter
483	Adjusted fix voltage DC2 beyond the accessible MPP range	1. Fix voltage was adjusted too high or too low	1. Check settings
484 - 485	Data transfer error	1. Communication problem caused by temporary environmental disturbances (grid / EMC, ...) 2. Ribbon cable between filter board and power stage set 3. Defective AC guard on filter board 4. Defective AC guard on power stage set	1. Automatically corrected 2. Change ribbon cable 3. Change filter board 4. Change AC board

### **Service class 5 - 6**

Class 5 status codes do not generally prevent the feeding of energy into the grid, but can restrict it. A status code is displayed until it is acknowledged by pressing a key (the inverter, however, continues to operate normally in the background).

Code	Description	Behaviour	Remedy
502	An isolation fault between DC+ / DC- to earth has been detected	1. Isolation fault at the PV generator	1. Check cables and PV generator
509	No feed-in operation for 24 hours	1. Snow covered or very dirty modules 2. Insufficient power from the modules for feed in operation	1. Clean modules or remove snow 2. Check other service codes
515	EEPROM communication failure	1. Occurs once 2. Filter calibration value not correct	1. Restart inverter 2. Change AC board. Afterwards if necessary DC board
516	Communication error inside the power stage set	1. Occurs once 2. Power stage set defective	1. Restart inverter 2. Change board
517	Power stage set derating caused by too high temperature	1. Ventilation opening blocked 2. Too high ambient temperature 3. Fan cables not connected 4. Fan defective 5. Bad contact: power modul <-> heat sink 6. Filter board defective 7. Recerbo defective 8. Measuring error on the power stage set	1. Clean openings 2. Change mounting place 3. Connect fan cables 4. Change fan 5. Check phase change paste 6. Change filter board 7. Change Recerbo 8. Change board
519	Communication error inside the power stage set	1. Occurs once 2. Filter board defective	1. Restart inverter 2. Change filter board
520	No feed-in fpr 24 hours from DC1 Input	1. Snow covered or very dirty modules 2. Insufficient power from the modules for feed in operation 3. Input not used	1. Clean modules or remove snow 2. Check other service codes 3. Configure inverter as monostring
521	No feed-in fpr 24 hours from DC2 Input	1. Snow covered or very dirty modules 2. Insufficient power from the modules for feed in operation 3. Input not used	1. Clean modules or remove snow 2. Check other service codes 3. Configure inverter as monostring
522	DC LOW Ch1	1. DC main switch open 2. PV generator not connected 3. DC voltage too low for feeding in 4. Reversal voltage of PV generator 5. DC operating mode: fix voltage and wrong voltage 6. Measuring error on the power stage set	1. Close DC main switch 2. Connect PV generator 3. Wait for more irradiance or check modules 4. Change polarity of PV generator 5. Check MPP settings / voltage 6. Change DC board. Afterwards if necessary AC board

<b>Code</b>	<b>Description</b>	<b>Behaviour</b>	<b>Remedy</b>
523	DC LOW Ch2	<ol style="list-style-type: none"> <li>1. DC main switch open</li> <li>2. PV generator not connected</li> <li>3. DC voltage too low for feeding in</li> <li>4. Reversal voltage of PV generator</li> <li>5. DC operating mode: fix voltage and wrong voltage</li> <li>6. Measuring error on the power stage set</li> </ol>	<ol style="list-style-type: none"> <li>1. Close DC main switch</li> <li>2. Connect PV generator</li> <li>3. Wait for more irradiance or check modules</li> <li>4. Change polarity of PV generator</li> <li>5. Check MPP settings / voltage</li> <li>6. Change DC board. Afterwards if necessary AC board</li> </ol>
558	Country setup not supported by power stage set	<ol style="list-style-type: none"> <li>1. Old software</li> <li>2. Old software</li> <li>3. Incompatible hardware combinations</li> </ol>	<ol style="list-style-type: none"> <li>1. Software update</li> <li>2. Reload setup</li> <li>3. Check hardware components</li> </ol>
559	Feature nor supported by Recerbo	<ol style="list-style-type: none"> <li>1. Old software</li> <li>2. Old software</li> <li>3. Incompatible hardware combinations</li> </ol>	<ol style="list-style-type: none"> <li>1. Software update</li> <li>2. Reload setup</li> <li>3. Check hardware components</li> </ol>
560	Power reduction because of over frequency	<ol style="list-style-type: none"> <li>1. Too high grid frequency</li> <li>2. Grid disturbances</li> <li>3. Wrong settings</li> </ol>	<ol style="list-style-type: none"> <li>1. Automatically corrected</li> <li>2. Software update</li> <li>3. Check settings</li> </ol>
565	AFCI SD card failure	<ol style="list-style-type: none"> <li>1. Writing data to SD card failed</li> </ol>	<ol style="list-style-type: none"> <li>1. Format SD card</li> </ol>
566	AFCI deactivated	<ol style="list-style-type: none"> <li>1. No error, AFCI is deactivated</li> </ol>	<ol style="list-style-type: none"> <li>1. If AFCI has to be switched on, use tool</li> </ol>
567	GVDPR active	<ol style="list-style-type: none"> <li>1. Too high grid voltage</li> <li>2. Grid disturbances</li> <li>3. Wrong settings</li> </ol>	<ol style="list-style-type: none"> <li>1. Automatically corrected</li> <li>2. Software update</li> <li>3. Check settings</li> </ol>
568	Multifunction current interface Warning	An external custom device performs a signal state change	Check the external signal or the input signal configuration
601	Internal communication fault	<ol style="list-style-type: none"> <li>1. Occurs once</li> <li>2. Occurs permanently</li> </ol>	<ol style="list-style-type: none"> <li>1. Restart inverter</li> <li>2. Change AC board</li> </ol>
602	Auto test Italy failed	<ol style="list-style-type: none"> <li>1. Auto test Italy was started and not finished or failed</li> </ol>	<ol style="list-style-type: none"> <li>1. Reload setup</li> </ol>
603	Temperature sensor in $\mu$ C defect (Ch3 AC Temp)	<ol style="list-style-type: none"> <li>1. Defective temperature sensor <math>\mu</math>C</li> <li>2. Defective circuit on the power stage</li> </ol>	<ol style="list-style-type: none"> <li>1. Change power stack</li> <li>2. Change AC board</li> </ol>
604	Temperature sensor in DC module 2 defect (Ch4 DC2)	<ol style="list-style-type: none"> <li>1. Defective temperature sensor in DC module 2</li> <li>2. Defective circuit on the power stage</li> </ol>	<ol style="list-style-type: none"> <li>1. Change DC board</li> <li>2. Change DC board</li> </ol>
607	RCMU continous fault occured more than 4 times in 24 hours	<ol style="list-style-type: none"> <li>1. Grounding problem</li> </ol>	<ol style="list-style-type: none"> <li>1. Automatically corrected after 24 hours</li> <li>2. Check PV array</li> <li>3. Check wiring</li> </ol>

## Service class 7 - 10

Class 7 status codes related to control system, the configuration and inverter data recording, and may directly or indirectly affect the process of feeding energy into the grid.

Code	Description	Behaviour	Remedy
701*	LN node type out of range	1. Wrong LN number 2. EEPROM defective	1. Insert LN number again 2. Change Recerbo
702*	Recerbo buffer full	1. Problems with LN ring 2. Recerbo defective	1. Check LN ring 2. Change Recerbo
703*	LN send buffer full	1. Problems with LN ring 2. Recerbo defective	1. Check LN ring 2. Change Recerbo
705*	LN number exists 2 times	1. LN number exists 2 times	1. Change LN number, LN number must be unique
706* - 707*	Key controller communication failed	1. Occurs once 2. Recerbo defective	1. Automatically corrected 2. Change Recerbo
711*	EEPROM error	1. Recerbo defective	1. Change Recerbo
712*	Failure while writing on EEPROM	1. Occurs once	1. Automatically corrected
713	EEPROM data could not be read completely	1. Occurs once 2. Recerbo defective	1. Automatically corrected 2. Change Recerbo
714* - 715*	Failure while reading from EEPROM	1. Occurs once 2. Recerbo defective	1. Automatically corrected 2. Change Recerbo
721	Failure while writing on EEPROM	1. Occurs once 2. Recerbo defective	1. Automatically corrected 2. Change Recerbo
722* - 726*	Failure while reading / writing from EEPROM	1. Occurs once 2. Recerbo defective	1. Automatically corrected 2. Change Recerbo
727* - 730*	EEPROM backup defective	1. Occurs once 3. Recerbo defective	1. Automatically corrected 3. Change Recerbo
731	Failure while initialising, USB flash drive was not detected	1. USB flash drive read / write protected 2. USB flash drive not detected 3. USB flash drive not supported 4. Access time of the inverter too fast	1. Remove read / write protection 2. Format USB flash drive 3. Use another USB flash drive 4. Update software
732	Failure while initialising, USB flash drive has a too high current	1. USB flash drive ineligible due to too high current	1. Use another USB flash drive
733	No USB flash drive inserted, although there should be	1. No USB flash drive inserted 2. Unplugged USB flash drive while updating	1. Insert USB flash drive 2. Reconnect USB flash drive and start update again
734	Update file not identified	1. Update file has wrong format 2. Update in the wrong file	1. Name update file correctly (e.c. Froxxxxx.upd) 2. Store update on root directory

<b>Code</b>	<b>Description</b>	<b>Behaviour</b>	<b>Remedy</b>
735	For this inverter no fitting update is on the USB flash drive	<ol style="list-style-type: none"> <li>1. Old or defective update on the USB flash drive</li> <li>2. Update file from another inverter</li> <li>3. Compatibility error</li> </ol>	<ol style="list-style-type: none"> <li>1. Load new update on the USB flash drive</li> <li>2. Use the correct update file</li> <li>3. Check hardware components</li> </ol>
736	Read or write error appeared	<ol style="list-style-type: none"> <li>1. Incorrectly formatted USB flash drive</li> <li>2. USB flash drive secured with a password</li> <li>3. Read or write protection on the USB flash drive</li> </ol>	<ol style="list-style-type: none"> <li>1. Format USB flash drive with FAT32</li> <li>2. Delete password protection</li> <li>3. Delete read or write protection</li> </ol>
737	Update file couldn't be opened	<ol style="list-style-type: none"> <li>1. Defective update file</li> <li>2. Failure while formatting</li> </ol>	<ol style="list-style-type: none"> <li>1. Load new update on the USB flash drive</li> <li>2. Format USB flash drive</li> </ol>
738	Creating a Logfile is not possible	<ol style="list-style-type: none"> <li>1. Incorrectly formatted USB flash drive</li> <li>2. USB flash drive secured with a password</li> <li>3. Read or write protection on the USB flash drive</li> </ol>	<ol style="list-style-type: none"> <li>1. Format USB flash drive with FAT32</li> <li>2. Delete password protection</li> <li>3. Delete read or write protection</li> </ol>
740	Failure while writing initialising	<ol style="list-style-type: none"> <li>1. Failure in the USB flash drive format</li> <li>2. Defective USB flash drive</li> </ol>	<ol style="list-style-type: none"> <li>1. Format USB flash drive</li> <li>2. Use another USB flash drive</li> </ol>
741	Failure while writing on USB flash drive	<ol style="list-style-type: none"> <li>1. Memory on USB flash drive full</li> <li>2. Memory on USB flash drive too small</li> <li>3. USB flash drive unplugged while writing</li> <li>4. Mains voltage drop out while writing</li> <li>5. Invalid data</li> </ol>	<ol style="list-style-type: none"> <li>1. Delete data from USB flash drive</li> <li>2. Use a bigger USB flash drive</li> <li>3. Reconnect USB flash drive and start update again</li> <li>4. Check grid</li> <li>5. Format USB flash drive</li> </ol>
743	Update failed	<ol style="list-style-type: none"> <li>1. Unplugged USB flash drive while updating</li> <li>2. Update failed</li> <li>3. Read or write protection on the USB flash drive</li> <li>4. Compatibility error</li> </ol>	<ol style="list-style-type: none"> <li>1. Reconnect USB flash drive and start update again</li> <li>2. Restart update</li> <li>3. Delete read or write protection</li> <li>4. Check hardware components</li> </ol>
745	Checksum test failed	<ol style="list-style-type: none"> <li>1. File on USB flash drive is defective</li> </ol>	<ol style="list-style-type: none"> <li>1. Format USB flash drive</li> </ol>
746	One or more boards could not be identified	<ol style="list-style-type: none"> <li>1. Boards have not started completely yet</li> <li>2. Boards have not started completely yet</li> <li>3. Print data of some boards are incompatible</li> </ol>	<ol style="list-style-type: none"> <li>1. Wait 1 minute with the update</li> <li>2. See device -&gt; info menu: all versions available?</li> <li>3. Change inverter</li> </ol>

<b>Code</b>	<b>Description</b>	<b>Behaviour</b>	<b>Remedy</b>
751	Lost real time clock	1. Inverter had no AC connection for longer than 5 days 2. Memory of the Recerbo defective	1. Set time 2. Change Recerbo
754* - 755*	Time set	1. Time / data has been set	
757	Time can not be stored, due to safety reasons the inverter does not feed in	1. Defective real time clock	1. Change Recerbo
758	RTC quartz in emergency operation	1. Occurs once 2. Recerbo defective	1. Automatically corrected 2. Change Recerbo
760	Systemquarz defective	1. Occurs once 2. Recerbo defective	1. Automatically corrected 2. Change Recerbo
761*	Reading error of on-board storage print	1. On-board storage print is missing 2. Defective ribbon cable 3. Recerbo defective 4. On-board storage print is defective	1. Change interface board with the one containing the on-board storage print 2. Change ribbon cable 3. Change Recerbo 4. Change inverter
762*	Reading error of attached storage print	1. Attached storage print is missing 2. Defective ribbon cable 3. Recerbo defective 4. Attached storage print is defective	1. Usage / attach the original storage print 2. Change ribbon cable 3. Change Recerbo 4. Change inverter
763*	Power limitation of the on-board storage print not readable	1. On-board storage print is missing 2. Recerbo defective 3. On-board storage print is defective	1. Usage / attach the original storage print 2. Change Recerbo 3. Change inverter
765*	Recerbo can not read power limitation	1. Recerbo defective	1. Change Recerbo
766	No power limitation found	1. Recerbo defective 2. On-board or attached storage print is defective	1. Change Recerbo 2. Change inverter
767*	Power limitation not readable	1. Occurs once 2. Recerbo defective	1. Automatically corrected 2. Change Recerbo
768	Power limitation while feeding-in operation changed	1. Attached storage print is being connected or disconnected during feeding in operation	1. Automatically corrected
772	Memory on the storage print not available, due to safety reasons the inverter does not feed in	1. SSP not connected	1. Check SSP
773	Memory on the storage print not initialised, due to safety reasons the inverter does not feed in	1. Memory not programmed or memory lost 2. Defective Recerbo	1. Reload setup 2. Change Recerbo

<b>Code</b>	<b>Description</b>	<b>Behaviour</b>	<b>Remedy</b>
775	Faulty programming of the power stage set	1. Power stage set or filter board not programmed	1. See device -> info menu: look for missing versions infos and change defective print
782* - 783*	Error during update	1. Occurs once 2. Recerbo defective	1. Automatically corrected 2. Change Recerbo
784*	Waiting on flash / busy	1. Occurs once 2. Recerbo defective	1. Automatically corrected 2. Change Recerbo
789*	Setup CRC failed	1. Wrong / defective data in flash 2. Recerbo defective	1. Update software 2. Change Recerbo
794*	Flash data structure defect	1. Wrong / defective data in flash 2. Recerbo defective	1. Update software 2. Change Recerbo
901	Deviation of measurement channel 1	Current of channel 1 deviates from the other channels	Check settings, DC fuse and modules
902	Deviation of measurement channel 2	Current of channel 2 deviates from the other channels	Check settings, DC fuse and modules
903	Deviation of measurement channel 3	Current of channel 3 deviates from the other channels	Check settings, DC fuse and modules
904	Deviation of measurement channel 4	Current of channel 4 deviates from the other channels	Check settings, DC fuse and modules
905	Deviation of measurement channel 5	Current of channel 5 deviates from the other channels	Check settings, DC fuse and modules
990	Deviation of output from radiation sensor value too big	Difference between the performance of the irradiation sensor and that of the inverter too big	Check archives values, shadow of the modules, blown string fuse or defect
991	Deviation of radiation sensor too big	The radiation sensor deviates too far	Check if your radiation sensor is soiled, shaded or defect
992	No radiation sensor values or value(s) not permitted	The radiation sensor does not return any values or returns values that are not permitted	Check the cable lines of the radiation sensor
993	Faulty energy report	Faulty energy report due to missing archive values	Check archive values at Fronius Solar.web server or Datalogger
996	No connection to Fronius Solar.web	No connection to Fronius Solar.web	1. Check LED status on Datalogger 2. Restart Datalogger 3. Check internet connection 4. Check if customer has got timer to switch off internet connection and time interval settings is too short
997	Deviation between inverters	Deviation of the kWh value between inverters depending on the settings in Fronius Solar.web	Check settings in system administration in Fronius Solar.web (real Wpeak per inverter and deviation), inquire if there are shadows etc.

Code	Description	Behaviour	Remedy
998	Fronius Solar.net loop is open more than 24h	Fronius Solar.net is not closed and the X-LED is red on the Datamanager or Datalogger	<ol style="list-style-type: none"> <li>1. Check Fronius Solar.net loop</li> <li>2. Check network cabling</li> <li>3. Check Fronius Com Card</li> </ol>
999	24h no feed in	<ol style="list-style-type: none"> <li>1. No communication between inverter and Datamanager or Datalogger more than 24h</li> <li>2. No communication between Fronius Sensor Card and Datamanager or Datalogger more than 2h</li> </ol>	<ol style="list-style-type: none"> <li>1. Check LED status from Datamanager or Datalogger</li> <li>2. Check archive values and Fronius Solar.net loop</li> </ol>
1000* - 1001*	Service-Message	Are harmless for a faultless feeding in process and gives information about the internal processor status	
1201* - 1210*	Service-Message	Are harmless for a faultless feeding in process and gives information about the internal processor status	

\* ... Code appears only with Eventlogging and in the Error Counter

**Customer service** **IMPORTANT!** Contact your Fronius dealer or a Fronius-trained service technician if

- an error appears frequently or all the time
- an error appears that is not listed in the tables

**Operation in dusty environments** When operating the inverter in extremely dusty environments: when necessary, clean the cooling elements and fan on the back of the inverter as well as the air intakes at the mounting bracket using clean compressed air.

# Error flowchart

---

## General


The error search tree is used to systematically locate and rectify errors.

Before starting any troubleshooting activities, read the "Function overview" section in order to understand the layout of the device and how it works.


Essential system data:

- Inverter type
  - Serial number of the installed inverter
  - Service code shown on the display (State PS menu)
  - Name of PV system (name of system operator)
  - System operating period
  - Location of system
  - Number of inverters installed in system (type, serial number)
  - DC and AC voltage
- 


## Permanent faults



Temporary faults



Abnormal behaviour





# **Changing components**



# General

## Safety



**WARNING!** An electric shock can be fatal. Before opening the device:

- If applicable, turn the mains switch to the O position
- Unplug the device from the mains
- Disconnect the inverter from the DC side
- Using a suitable measuring instrument, ensure that electrically charged parts (e.g. capacitors) are fully discharged
- Restrict access to the working area
- Take steps to ensure the metallic surfaces of the device cannot be touched
- Suitable protective clothing and/or equipment must be worn when carrying out the test or the repair



**WARNING!** An electric shock can be fatal. Danger due to residual voltage in capacitors. Wait for the capacitors to discharge. See the operating instructions and the safety notices on the inverter for more details on the discharge time.



**WARNING!** Incorrect operation or poorly executed work can cause serious injury or damage. Commissioning of the inverter may only be carried out by trained personnel in accordance with the technical regulations. The "Safety Rules" section must be read prior to commissioning the equipment or carrying out servicing or repair work.



**WARNING!** An electric shock can be fatal. Danger due to mains voltage and DC voltage from solar modules.

- The connection area must only be opened by an authorised electrician.
- The separate area containing the power stage sets must only be disconnected from the connection area when in a de-energised state.
- The separate area containing the power stage sets must only be opened by a Fronius-trained service technician.
- Make sure that both the AC side and the DC side of the inverter are de-energised before making any connections.



**WARNING!** An inadequate ground conductor connection can cause serious injury or damage. The housing screws provide a suitable ground conductor connection for earthing the housing and must NOT be replaced by any other screws that do not provide a reliable ground conductor connection.




**NOTE!** Requirements concerning electrical installations may be subject to national standards and directives, which must be observed.

A safety inspection must be carried out after replacement, maintenance or repair work on any component (see "Safety inspection").


## Measuring the intermediate circuit voltage



**WARNING!** Risk of electric shock! Despite the intended discharge circuit, a dangerous voltage can be present in the intermediate circuit for a long time. To ensure safe operation, wait for the capacitors to discharge and then measure the intermediate circuit voltage with a suitable measuring device. The voltage must not exceed 30 V DC. The measuring points are shown in the following pictures.



Measuring points Fronius Eco



Measuring points Fronius Symo 10 - 20 kW

## ESD guidelines



**NOTE!** Observe ESD guidelines when handling electronic components and PC boards. This primarily applies to ESD compatible

- Packaging
- Work surfaces
- Floors
- Seating
- Earthing facilities
- Handling

No guarantee or warranty claims can be made in respect of any improperly handled electronic component or PC board.

## General

The "Changing components" section describes how to replace components that:

- Have no instructions of their own for replacement and
- Require detailed replacement instructions

## Overview

The "Replacing components" chapter is divided into the following sections:

- Opening and closing the device
- Replacing the DC disconnecter
- Replacing the Eco DC disconnecter
- Replacing the Eco fuse
- Replacing the Overvoltage PC board
- Replacing the external fan
- Replacing the internal fan
- Replacing the Eco internal fan
- Replacing the Datamanager card / WLAN option
- Replacing the display PC board - Recerbo
- Replacing the filter PC board - SymoFIL
- Replacing the filter PC board - EcoFIL
- Replacing the power board - SymoPS AC
- Replacing the power board - SymoPS DC
- Replacing the power board - EcoPS
- Replacing other components

# Changing components

## Safety



**WARNING!** An electric shock can be fatal. Before opening the device:

- Move the mains switch to the O position
- Unplug the device from the mains
- Put up an easy-to-understand warning sign to stop anybody inadvertently switching it back on again
- Using a suitable measuring instrument, ensure that electrically charged parts (e.g. capacitors) have been discharged



**WARNING!** An electric shock can be fatal. Danger due to residual voltage in capacitors. Wait for the capacitors to discharge. The discharge time is 6 minutes. See the operating instructions and the safety notices on the inverter for more details on the discharge time.




**NOTE!** Requirements concerning electrical installations may be subject to national standards and directives, which must be observed.

A safety inspection must be carried out after replacement, maintenance or repair work on any component (see "Safety inspection").

## Opening and closing the device

### Opening the device:



**WARNING!** Observe the safety rules (see the beginning of the "Safety" section)

- 1 Set the DC disconnect (1) to the 0 position
- 2 Undo the four 5x25 TX25 screws (2) and remove the Datcom cover
- 3 If applicable, disconnect all plug connections
- 4 Undo the two 5x25 TX25 screws (3)






**NOTE!** To avoid damaging the base shell, do not angle the inverter by more than 11°.



**WARNING!** Wait for the capacitors to discharge before continuing.

- 5** Lift the inverter from the Datcom area, disconnecting the connection to the wall bracket
- 6** Detach the inverter by lifting it upwards



- 7** Undo the six 5x16 TX25 screws (4) and remove the power stage set cover by lifting it clear
  - Fronius Eco: Remove EMC bracket

**Closing the device:**




**NOTE!** To ensure a sufficient EMC connection is established, all EMC springs must be present

- 1** Make sure that the eleven EMC springs are seated correctly - slight notches hold the EMC springs in place

(The Overvoltage PC board is necessary on position (5))

Symo 10-20 / US, Eco / 15.0



- 2** Fit the power stage set cover with six 5x18 TX25 screws (4)  
**[3 Nm]**

– Fronius Eco: Fit EMC bracket

**NOTE!** If the screws no longer fit tightly, they must be replaced with new 5x25 TX25 screws [42,0401,4231]




**NOTE!** To avoid damaging the base shell, do not angle the inverter by more than 11°.

- 3** Attach the inverter at the top and allow it to engage in the wall bracket

- 4** Fit the two 5x25 TX25 screws (3) to hold the inverter securely in the wall bracket  
**[2,5 Nm]**






- 5** If applicable, connect all plug connections




- 6** Fit the Datcom cover with four 5x25 TX25 screws (2)  
**[2,5 Nm]**

- 7** Set the DC disconnect (1) to the I position


# Replacing thread- ed bushings in the base shell





**Replacing the DC disconnect**

**Removing the DC disconnect:**




**WARNING!** Observe the safety rules (see the beginning of the "Safety" section)

- 1** Remove the inverter from the wall bracket (see "Opening and closing the device")




**WARNING!** Take safety precautions. Observe the safety rules - DC voltage present!

- 2** Disconnect the AC and DC leads from the terminal block of the DC disconnect
- 3** Remove the retaining clip (1) and control switch with shaft (2)




- 4** Undo the three 4x20 TX20 screws (3) and remove the strain relief clamp
- 5** Undo the four 4x9 TX20 screws (4) and remove the DC disconnect

**Inserting the DC disconnect:**



- 1** Insert the new DC disconnect and secure it with four 4x9 TX20 screws (4) **[2 Nm]**
- 2** Fix the strain relief clamp using three 4x20 TX20 screws (3) **[3-4 turns]**



- 3 Insert the control switch and shaft (2) and secure it with the retaining clip (1)




**WARNING!** Take safety precautions. Observe the safety rules - DC voltage present!

- 5 Connect the AC and DC lines to the terminal block of the DC disconnect
- 6 Place the inverter in the wall bracket (see "Opening and closing the device")

### Replacing the DC disconnector Eco

#### Removing the DC disconnector:




**WARNING!** Observe the safety rules (see the beginning of the "Safety" section)

- 1 Remove the inverter from the wall bracket (see "Opening and closing the device")




**WARNING!** Take safety precautions. Observe the safety rules - DC voltage present!

- 2 Disconnect the AC and DC leads from the terminal block of the DC disconnect
- 3 Remove the retaining clip (1) and control switch with shaft (2)




- 4 Undo the three 4x20 TX20 screws (3) and remove the strain relief clamp
- 5 Undo the four 4x9 TX20 screws (4) and remove the DC disconnector

#### Inserting the DC disconnector:



- 1 Insert the new DC disconnect and secure it with four 4x9 TX20 screws (4) [2 Nm]
- 2 Fix the strain relief clamp using three 4x20 TX20 screws (3) [3-4 turns]



- 3 Insert the control switch and shaft (2) and secure it with the retaining clip (1)




**WARNING!** Take safety precautions. Observe the safety rules - DC voltage present!

- 5 Connect the AC and DC lines to the terminal block of the DC disconnect
- 6 Place the inverter in the wall bracket (see "Opening and closing the device")

## Replacing the Eco fuse


### Removing the Eco fuse:



**WARNING!** Observe the safety rules (see the beginning of the "Safety" section)


- 1 Take the inverter out of the wall bracket and remove the DC disconnect Eco (see "Opening and closing the device" and "Replacing the DC disconnecter Eco" sections)

- 2 Undo the three TX20 screws (1)



- 3 Undo the seven 4x12 TX20 screws (2) and remove the Eco fuse


### Inserting the Eco fuse:



- 1 Insert the new Eco fuse and secure it with seven 4x12 TX20 screws (2) [1.5 Nm]

- 2 Tighten the three TX20 screws (1)

- 3 Insert the DC disconnect Eco, close the inverter and place it in the wall bracket (see "Replacing the DC disconnecter Eco" and "Opening and closing the device" sections)




## Replacing the Overvoltage PC board Eco





**NOTE!** The SymoPS DC power board from version V1.4A\_B already has an integrated overvoltage function. If the SymoPS DC replacement PC board is version V1.4A\_B or higher, any existing OVP SYMPRI overvoltage PC board must be removed.

### Removing the overvoltage PC board:




**WARNING!** Observe the safety rules (see the beginning of the "Safety" section)

- 1 Take the inverter out of the wall bracket and open it (see "Opening and closing the device" section)
- 2 Remove the insulation sheet (1)
- 3 Undo the plug connection to the OVP (2)
- 4 Undo the two 4x9 TX20 screws (3)
- 5 Undo cable connection (4)
- 6 Undo the plug connection to the PS (5)
- 7 Remove the overvoltage PC board




- 8 Detach and remove the OVP retaining plate (6) at the marked spots


### Inserting the overvoltage PC board:




- 1 Attach the OVP retaining plate (6) at the marked spots



- 2 Move the relay switch to the correct position



- 3 Insert the overvoltage PC board
- 4 Establish cable connection (4)
- 5 Establish a connection to the PS (5)




- 6** Mount the new overvoltage PC board with two 4x9 TX20 screws (3)  
**[2 Nm]**
- 7** Establish a connection to the OVP (5)
- 8** Insert insulating sheet (1)
- 9** Close the inverter and place it into the wall bracket (see “Opening and closing the device“ section)

## Replacing the overvoltage PC board - Symo




**NOTE!** The SymoPS DC power board from version V1.4A\_B already has an integrated overvoltage function. If the SymoPS DC replacement PC board is version V1.4A\_B or higher, any existing OVP SYMPRI overvoltage PC board must be removed.

### Removing the overvoltage PC board:




**WARNING!** Observe the safety rules (see the beginning of the "Safety" section)


- 1 Take the inverter out of the wall bracket and open it (see "Opening and closing the device" section)
- 2 Remove the insulation sheet (1)
- 3 Undo the three 4x9 TX20 screws of the cable connections (2)
- 4 Undo the two 4x9 TX20 screws (3)



- 5 Undo the plug connection to the PS(4)




- 6 Undo the plug connection to the OVP (5)
- 7 Remove the overvoltage PC board




**8** Detach and remove the OVP retaining plate (6) at he marked spots


**Inserting the overvoltage PC board:**




**1** Attach the OVP retaining plate (6) at the marked spots




**2** Move the relay switch to the correct position



- 3** Insert the overvoltage PC board
- 4** Establish a connection to the OVP (5)



- 5** Establish cable connection (4)




- 6** Mount the new overvoltage PC board with two 4x9 TX20 screws (3)  
**[2 Nm]**

**IMPORTANT!** Make sure that cable connections A (short), B (medium) and C (long) are bent in such a way they point away from the PC board (see illustration)

- 7** Mount cable connection (2) with three 4x9 TX20 screws  
**[2 Nm]**
- 8** Insert insulating sheet (1)
- 9** Close the inverter and place it into the wall bracket (see “Opening and closing the device” section)

## Replacing the external fan

### Removing the external fan:




**WARNING!** Observe the safety rules (see the beginning of the "Safety" section)


- 1 Take the inverter out of the wall bracket and open it (see "Opening and closing the device")
- 2 Unplug the fan cable (1) from the SymoFIL / EcoFIL




**NOTE!** Turn the inverter carefully so that the back of the inverter is accessible.



- 3 Pull off the two rubber seals (2)
- 4 Take the fan cable out of both strain-relief devices
- 5 Pull off the cable gland (3)
- 6 Thread out the fan cable




- 7 Undo the eight 4x8 TX25 screws (4) and remove the air guide plate




- 8** Undo the two 5x10 TX25 screws (5) and remove the external fan

**Inserting the external fan:**




**NOTE!** Ensure the flow of air is into the device!

- 1** Fit the new external fan with two 5x10 TX25 screws (5) **[1.5 Nm]**




- 2** Fit the air guide plate with eight 4x8 TX25 screws (4) **[1.5 Nm]**



- 3 Thread in the fan cable, pushing in the cable gland (3) as you do so
- 4 Feed the fan cable through both strain-relief devices
- 5 Fit the two rubber seals (2)



**WARNING!** To ensure there are no leaks, the cable gland must be securely in place




**NOTE!** Carefully turn the inverter round.

- 5 Plug the fan cable (1) into the SymoFIL / EcoFIL
- 6 Close the inverter and place it in the wall bracket (see "Opening and closing the device")

Switch on the inverter and then carry out a fan test via the display (see operating instructions)

## Replacing the Symo internal fan


### Removing the internal fan:



**WARNING!** Observe the safety rules (see the beginning of the "Safety" section)

- 1 Take the inverter out of the wall bracket and open it (see "Opening and closing the device")
- 2 Unplug the fan cable (1) from the SymoPS
- 3 Use a slotted screwdriver to undo the expanding rivets (2)
- 4 Remove the internal fan

### Inserting the internal fan:




**NOTE!** Observe the direction of the air flow in the device.

- 1 Insert the internal fan
- 2 Use a slotted screwdriver to press in the expanding rivets (2)
- 3 Plug in the fan cable (1) into the SymoFIL
- 4 Close the inverter and place it in the wall bracket (see "Opening and closing the device")

Switch on the inverter and then carry out a fan test via the display (see operating instructions)

## Replacing the Eco internal fan


### Removing internal fan 1:



**WARNING!** Observe the safety rules (see the beginning of the "Safety" section)

- 1 Take the inverter out of the wall bracket and open it (see "Opening and closing the device")
- 2 Disconnect the fan cable (1) from the EcoPS
- 3 Use a slotted screwdriver to undo the expanding rivets (2)
- 4 Remove the internal fan

### Inserting internal fan 1:




**NOTE!** Ensure the flow of air is into the device!

- 1 Insert the internal fan
- 2 Use a slotted screwdriver to press in the expanding rivets (2)
- 3 Connect the fan cable (1) to the EcoPS
- 4 Close the inverter and place it in the wall bracket (see "Opening and closing the device")


Switch on the inverter and then carry out a fan test via the display (see operating instructions)

### Removing internal fan 2:




**WARNING!** Observe the safety rules (see the beginning of the "Safety" section)

- 1 Disconnect the fan cable (1) from the EcoPS
- 2 Use a slotted screwdriver to undo the expanding rivets (2)
- 3 Remove the internal fan module




- 4 Use a slotted screwdriver to undo the expanding rivets (3)
- 5 Remove the internal fan

**Inserting internal fan 2:**



**NOTE!** Ensure the flow of air is away from the fan holder!

- 1 Insert the internal fan
- 2 Use a slotted screwdriver to press in the expanding rivets (3)




- 3 Insert the internal fan module
- 4 Use a slotted screwdriver to press in the expanding rivets (2)
- 5 Connect the fan cable (1) to the EcoPS
- 6 Close the inverter and place it in the wall bracket (see "Opening and closing the device")

Switch on the inverter and then carry out a fan test via the display (see operating instructions)

## Replacing the Datamanager card WLAN option

### Removing the Datamanager card:



**WARNING!** Observe the safety rules (see the beginning of the "Safety" section)

- 1 Take the inverter out of the wall bracket and open it (see "Opening and closing the device")


#### Datamanager Card:

- 2 Unplug the 12-pin plug connector (1) from the Datamanager PC board
- 3 Use a flat spanner to take off the antenna (2)
- 4 Undo the 4x8 TX20 Taptite screw (3)
- 5 Unplug the Datamanager card from the Recerbo PC board and remove it

#### Datamanager Card 2:

- 2 Unplug the 16-pin plug connector (1) from the Datamanager 2 PC board
- 3 Use a flat spanner to take off the antenna (2)
- 4 Undo the 4x9 TX20 Taptite screw (3)
- 5 Unplug the Datamanager card from the Recerbo PC board and remove it

## Inserting the Datamanager card:



- 1 Insert the new Datamanager card and connect it to the Recerbo PC board

### Datamanager Card:



- 2 Fit the Datamanager PC board with a 4x8 TX20 Taptite screw (3)  
**[1.2 Nm]**
- 3 Use a flat spanner to fit the antenna (2)  
**[0.6 Nm]**
- 4 Fit the 12-pin plug connector (1) to the Datamanager PC board
- 5 Close the inverter and place it in the wall bracket (see "Opening and closing the device")

### Datamanager Card 2:

- 2 Fit the Datamanager 2 PC board with a 4x9 TX20 Taptite screw (3)  
**[1.2 Nm]**
- 3 Use a flat spanner to fit the antenna (2)  
**[0.6 Nm]**
- 4 Fit the 16-pin plug connector (1) to the Datamanager 2 PC board
- 5 Close the inverter and place it in the wall bracket (see "Opening and closing the device")

Replacing the display PC board - Recerbo

Removing the Recerbo:




**WARNING!** Observe the safety rules (see the beginning of the "Safety" section)

- 1 Take the inverter out of the wall bracket, open it and remove the Datamanager card (see "Opening and closing the device" and "Replacing the Data-manager card" sections)
- 2 Disconnect all connections from the Recerbo
- 3 Push the Recerbo holder locking devices (1) upwards
- 4 Remove the Recerbo module

**NOTE!** Take care when carrying out the next two steps not to damage any of the components

- 6 Take the holder (2) off the Recerbo
- 7 Break off the device data unit (3) from the faulty Recerbo

## Inserting the Recerbo:




- 1 The device data unit of the new Recerbo must also be broken off and returned to Fronius with the faulty Recerbo

 **NOTE!** If you forget to connect the device data unit or do not connect it correctly, the inverter will show status code 482 on the display

- 2 Connect the broken off device data unit (3) to the inside of the new Recerbo

- 3 Fit the Recerbo holder (2) to the new Recerbo
  - feed it in from above
  - press downwards

 **NOTE!** All guide bolts and pins must be properly engaged



- 4 Insert the new Recerbo module


- 5 The Recerbo holder locking devices (1) must be fully engaged in the housing shell

- 6 Reconnect all connections to the Recerbo

- 7 Insert the Datamanager card, close the inverter and place it in the wall bracket (see "Replacing the Datamanager card" and "Opening and closing the device" sections)


## Replacing the filter PC board - SymoFIL

### Removing the SymoFIL:




**WARNING!** Observe the safety rules (see the beginning of the "Safety" section)


- 1 Take the inverter out of the wall bracket and remove the Recerbo without detaching the device data unit (see "Opening and closing the device", "Replacing the display PC board - Recerbo" and necessary „Replacing the Overvoltage PC board“ sections)
- 2 Undo the 4x9 TX20 screw (1) on the ground connection
- 3 Undo the two 5x10 TX25 screws (2) and remove the Datcom insert
- 4 Disconnect all cables and plug connections (3) from the SymoFIL and thread them out
- 5 Undo the nine 4x9 TX20 screws (4)
- 6 Thread out the SymoFIL and remove it



### Inserting the SymoFIL:



- 1 On the new PC board SymoFIL, remove the protective film from the heat-transfer pad
- 2 Thread in the new SymoFIL and position it
- 3 Fit the SymoFIL with nine 4x9 TX20 screws (4)  
**[2 Nm]**



- 3 Connect all cables and plug connections (3) to the SymoFIL
- 4 Fit the Datcom insert with two 5x10 TX25 screws (2) **[1,2 Nm]**
- 5 Fit the ground connection with a 4x9 TX20 screw (1) **[2 Nm]**
- 6 Insert the Recerbo, close the inverter and place it in the wall bracket (see "Replacing the display PC board - Recerbo", "Opening and closing the device" and necessary „Replacing the Overvoltage PC board“ sections)

Switch on the inverter and then carry out a fan test via the display (see operating instructions)


### Replacing the filter PC board - EcoFIL

### Removing the EcoFIL:




**WARNING!** Observe the safety rules (see the beginning of the "Safety" section)


- 1 Take the inverter out of the wall bracket and remove the Recerbo without detaching the device data unit (see "Opening and closing the device", "Replacing the display PC board - Recerbo" and necessary „Replacing the Overvoltage PC board“ sections)
- 2 Undo the 4x9 TX20 screw (1) on the ground connection
- 3 Undo the two 5x10 TX25 screws (2) and remove the Datcom insert
- 4 Disconnect all cables and plug connections (3-4) from the EcoFIL and thread them out
- 5 Undo the nine 4x9 TX20 screws (5)
- 6 Thread out the EcoFIL and remove it




## Inserting the EcoFIL:




- 1 Remove the protective film from the thermally conductive pad for the new EcoFIL PC board and ensure that the pads do not slip out of place or fall off during installation.



- 2 Thread in and position the new EcoFIL
- 3 Fit the EcoFIL with nine 4x9 TX20 screws (5)  
[2 Nm]



- 4 Connect all cables and plug connections (3) to the EcoFIL
- 5 Fit the Datcom insert with two 5x10 TX25 screws (2)  
[1.2 Nm]
- 6 Fit the ground connection with a 4x9 TX20 screw (1)  
[2 Nm]




- 7 Fit the AC cable harness with four 5x10 TX20 screws (4)  
[3.5 Nm]
- 8 Insert the Recerbo, close the inverter and place it in the wall bracket (see "Replacing the display PC board - Recerbo", "Opening and closing the device" and necessary "Replacing the Overvoltage PC board" sections)

Switch on the inverter and then carry out a fan test via the display (see operating instructions)


## Replacing the power board - SymoPS AC

### Removing the SymoPS AC:



**WARNING!** Observe the safety rules (see the beginning of the "Safety" section)

- 1 Take the inverter out of the wall bracket and open it (see "Opening and closing the device")
- 2 Disconnect all cables and plug connections (1-2) and thread them out
- 3 Undo the twelve 4x9 TX20 screws (3)



- 4 Undo the six 4x9 TX20 screws (4) on the solar modules
- 5 Insert the screwdriver into the "Remove Print" hole (5) and detach the SymoPS AC from the heat sink in the direction of the arrow
- 6 Remove the SymoPS AC
- 7 Remove any old PCM paste residues from the heat sink using a clean cloth

**NOTE!** Ensure you remove all PCM paste residues

**NOTE!** If you are returning the SymoPS AC, the solar modules must also be cleaned with a clean cloth.


- Take the PCM film from the small parts kit
- Position it on the solar modules and smooth it out
- Ensure that all the protective film is removed!

## Inserting the SymoPS AC:



**NOTE!** Do not press on the marked area -> this will damage the PCM material

- 1 Detach the blister packs from the new SymoPS AC at the tabs and place them on the faulty SymoPS AC




**CAUTION!** The PCM paste must not be damaged or removed when inserting the SymoPS AC

- 2 Insert the new SymoPS AC and position accordingly



**NOTE!** To avoid applying mechanical stress to the solar modules, apply the torque in the same sequence

- 3 Fit the SymoPS AC solar modules with six 4x9 TX20 screws (4). Observe the torque sequence to avoid applying mechanical stress  
First pretension all six screws to **[0.5 Nm]** and then tighten them to **[2 Nm]**



- 4 Thread in and connect all cables and plug connections (1-2)

- 5 Fit the SymoPS AC with twelve 4x9 TX20 screws (3) **[2 Nm]**



**NOTE!** Ensure that the ferrite cores and their holders are fitted correctly

- 6 Close the inverter and place it in the wall bracket (see "Opening and closing the device")


Switch on the inverter and then carry out a fan test via the display (see operating instructions)

## Replacing the power board - SymoPS DC




**NOTE!** The SymoPS DC power board from version V1.4A\_B already has an integrated overvoltage function. If the SymoPS DC replacement PC board is version V1.4A\_B or higher, any existing OVP SYMPRI overvoltage PC board must be removed.

### Removing the SymoPS DC:



**WARNING!** Observe the safety rules (see the beginning of the "Safety" section)

- 1 Take the inverter out of the wall bracket and open it (see "Opening and closing the device" and necessary „Replacing the Overvoltage PC board“ sections)
- 2 Disconnect all cables and plug connections (1) and thread them out
- 3 Undo the 13/15 4x9 TX20 screws (2)



- 4 Undo the four 4x9 TX20 screws (3) on the solar modules
- 5 Insert the screwdriver into the "Remove Print" hole (4) and detach the SymoPS DC from the heat sink in the direction of the arrow
- 6 Remove the SymoPS DC
- 7 Remove any old PCM paste residues from the heat sink using a clean cloth



**NOTE!** Ensure you remove all PCM paste residues



**NOTE!** If you are returning the SymoPS DC, the solar modules must also be cleaned with a clean cloth.


- Take the PCM film from the small parts kit
- Position it on the solar modules and smooth it out
- Ensure that all the protective film is removed!

### Inserting the SymoPS DC:



**NOTE!** Do not press on the marked area -> this will damage the PCM material

- 1 Detach the blister packs from the new SymoPS DC at the tabs and place them on the faulty SymoPS DC




**CAUTION!** The PCM paste must not be damaged or removed when inserting the SymoPS DC

- 2 Insert the new SymoPS DC and position accordingly

**NOTE!** To avoid applying mechanical stress to the solar modules, apply the torque in the same sequence

- 3 Fit the SymoPS DC solar modules with four 4x9 TX20 screws (3). Observe the torque sequence to avoid applying mechanical stress  
First pretension all four screws to **[0.5 Nm]** and then tighten them to **[2 Nm]**



- 4 Thread in and connect all cables and plug connections (1)

- 5 Fit the SymoPS DC with 13/15 4x9 TX20 screws (2) **[2 Nm]**


**NOTE!** Ensure that the ferrite cores and their holders are fitted correctly

- 6 Close the inverter and place it in the wall bracket (see "Opening and closing the device" and necessary „Replacing the Overvoltage PC board“ sections)

Switch on the inverter and then carry out a fan test via the display (see operating instructions)


**Replacing the power board - EcoPS**

**Removing the EcoPS:**



**WARNING!** Observe the safety rules (see the beginning of the "Safety" section)

- 1 Take the inverter out of the wall bracket and open it (see "Opening and closing the device" and necessary „Replacing the Overvoltage PC board“ sections)
- 2 Disconnect all cables and plug connections (1-2) and thread them out
- 3 Undo the 11 4x9 TX20 screws (3)



- 4 Undo the six 4x9 TX20 screws (4) on the solar modules
- 5 Remove the EcoPS
- 6 Remove any old PCM paste residues from the heat sink using a clean cloth



**NOTE!** Ensure you remove all PCM paste residues




**NOTE!** If you are returning the EcoPS, the solar modules must also be cleaned with a clean cloth.  
 - Take the PCM film from the small parts kit  
 - Position it on the solar modules and smooth it out  
 - Ensure that all the protective film is removed!

**Inserting the EcoPS:**



**NOTE!** Do not press on the marked area -> this will damage the PCM material

- 1 Detach the blister packs from the new EcoPS at the tabs and place them on the faulty EcoPS




**CAUTION!** The PCM paste must not be damaged or removed when inserting the EcoPS

**2** Insert the new EcoPS and position accordingly

**NOTE!** To avoid applying mechanical stress to the solar modules, apply the torque in the same sequence

**3** Fit the EcoPS solar modules with six 4x9 TX20 screws (4). Observe the torque sequence to avoid applying mechanical stress  
First pretension all six screws to **[0.5 Nm]** and then tighten them to **[2 Nm]**



**4** Thread in and connect all cables and plug connections (1)

**NOTE!** Observe the correct sequence for the screw joints

**5** Fit the AC cable harness with four 5x10 TX25 screws (2)  
**[3.5 Nm]**

**6** Fit the EcoPS with 11 4x9 TX20 screws (3)  
**[2 Nm]**

**NOTE!** Ensure that the ferrite cores and their holders are fitted correctly

**7** Close the inverter and place it in the wall bracket (see "Opening and closing the device" and necessary "Replacing the Overvoltage PC board" sections)

Switch on the inverter and then carry out a fan test via the display (see operating instructions)

---

## Replacing other components



**WARNING!** Observe the safety rules (see the beginning of the "Safety" section)

If the following components are faulty, the entire inverter must be replaced:

- Housing parts (excluding covers)
- Inductors
- Heat sinks
- Seals (not including the seals on the covers)

The covers (Datcom cover and power stage set cover) can be replaced as a component with an injection-moulded seal.

# **Safety Inspections**



# Safety Inspections

---

**Safety inspection** This section outlines the safety inspection for the device described in this service manual. It has been structured in compliance with "DIN VDE 0701-0702" and "ÖVE/ÖNORM E8701-1".

Please also be aware of the requirements and standards relevant to your country, as the measured values or steps taken during the tests may vary.

Should there be no relevant requirements and standards in your country, Fronius recommends that this test should still be carried out.

The safety inspection must only be carried out on a fully assembled device.

---

**Responsibility** The repair engineer is responsible for carrying out and documenting the safety inspection properly and for making the correct decision regarding the outcome of the inspection. Fronius accepts no liability in this respect.

Should any defects be identified during the test, then the entire safety inspection must be repeated once such defects have been rectified.

The following tests must be performed in the prescribed sequence. Each test must be passed before the next test is started. If it is not possible to perform a particular test, the examiner must decide whether the safety of the device can nevertheless still be verified. The examiner bears full responsibility and liability for this decision. Justifications for the resulting decision must be documented in the test record under "Comments".

---

**Area of application** A safety inspection must be performed after any repair, maintenance or modification work, or if stipulated by applicable national standards.

---

**Inspection staff qualifications** The safety inspection may only be performed by an appropriately qualified electrician. These are persons who due to their specialist training, knowledge and experience of the relevant regulations are able to evaluate the tasks they are assigned as well as to identify and avoid electrical and other possible hazards.

---

**Measuring instruments** The following requirements concerning measuring equipment as defined by DIN VDE 0701-0702 and ÖVE/ÖNORM E8701-1 must be observed. Also refer to the applicable requirements and standards in your country:

Ground conductor resistance

- The measuring voltage may be a direct or alternating voltage
- The open circuit voltage must remain within a range of 4 V to 24 V
- The measuring current within the measuring range of 0.2 Ω to 1.99 Ω must not drop below 0.2 A

#### Insulation resistance

- The measuring voltage value shown on the measuring device must be at least the same as the rated voltage to earth of the device to be tested, however it must be no less than 500 V DC voltage.
- The measuring current must be at least 1 mA (this corresponds to a load resistance of 0.5 M $\Omega$ ).

#### Ground conductor current

- The effective inner resistance of the ground conductor measuring device must not exceed 5  $\Omega$ . In the event of higher resistances, measures must be adopted to prevent dangerous contact voltages.
- The measuring range must cover at least 0.25 mA to 19 mA.
- The testing equipment must evaluate the measured current as an effective value regardless of the curve form.

#### Contact current

- The effective inner resistance of the contact current measuring device must be 1 k $\Omega$  to 2 k $\Omega$ .
- Should the current measuring circuit be inadvertently connected to a voltage up to 120% of the nominal grid voltage, the user must not be put at risk and the testing circuit must not be damaged.
- The testing equipment must evaluate the measured current as an effective value regardless of the curve form.

# Visual inspections

---

## General

The following must be visually inspected without any further dismantling of the device. Obvious defects in any safety-related device components are unacceptable. Defects that could pose a risk during the visual inspection must also be recorded.

Any defects that could cause other hazards must be repaired immediately or restrictions placed on the further use of the system until repairs have been effected.

---

## Mains supply and connecting lines

- Connecting lines and other cables must not be damaged or defective
- Insulation must not be damaged (do not use insulating or adhesive tapes to repair damage)
- Connectors and plug connections must not be damaged or deformed
- Strain-relief devices, bending-protection devices, line routings or mountings must all be effective
- Lines/plugs must be suitable for the application and the power level
- Fuse cartridges and device fuse holders must not be faulty

**IMPORTANT!** IEC 60364-5-52 serves as the basis for determining the cross-section and current capacity of mains cables. As the way the cables are laid and insulated, the ambient temperature and the current capacity can vary, the requirements set out in IEC 60364-5-52 are to be observed when changing mains leads. Also refer to the applicable requirements and standards in your country.

---

## Housing and covers

- All housing components, insulation components and protective covers must be present and undamaged
  - No unauthorised modifications must have been made (e.g. installations, conversions that have not been approved by the manufacturer)
  - Cooling openings must not be dirty or blocked and an air filter must be present
  - Any dirt, corrosion or degradation that impairs safety must not be visible
  - There must be no signs of overloading or improper use
  - There must not be any conductive objects in the housing
- 

## Adjustment and display devices

- Control elements and indicators must not be faulty
- 

## Rating plate and warning stickers

- Safety-related labels (e.g. warning notices, earthing symbols, rating plates, etc.) must be present. Replace, update or correct the labels as required
- The legibility of all safety-related labels or symbols, measurement data and positioning indicators must be ensured

# Electrical tests

## Insulation resistance



**WARNING!** An electric shock can be fatal. Some of the insulation resistance measurements are taken under high voltage. The process must be completely understood before starting the test. Observe the following safety precautions:

- Restrict access to the work area as far as possible.
- Do not touch any other person while performing the test and take measures to prevent other people touching any metallic surfaces.
- A voltage is applied to the area under test each time that the insulation resistance testing equipment is switched on. The insulation resistance testing equipment must be fitted with an automatic self-discharge device.
- Wear suitable protective clothing/protective equipment while conducting the test.
- When carrying out the insulation resistance test, do not touch any other person and put measures in place to prevent other people touching the back of the solar module or the terminals of the solar module with any part of their body.
- Ensure that the polarity is correct while conducting the insulation resistance test to avoid unreliable test results.



**WARNING!** As the module array voltage has not been isolated from the mounting bracket, the PV voltage is still present on the terminals.

These tests must be carried out while the cover is open. The insulation resistance test must be carried out separately on the mounting bracket and on the inverter.

- A thorough understanding of the tests is required before starting the work.
- The inverter must be taken out of the mounting bracket.
- The device being tested must be safely isolated from the AC grid (the grid lead [L, N] must not be connected). If the AC grid cannot be disconnected from the mounting bracket, the torques applied to all ground terminals must be checked.



**CAUTION!** Take safety precautions. Observe the safety rules - DC voltage present!

- Strings must not be disconnected from the mounting bracket. The insulation resistance test can be carried out when the module array is connected.
- All switches (DC disconnect at position I), controllers, etc. must be closed during the measurements.
- The inverter must be disconnected from Fronius Solar Net and from the Datcom ring.
- The polarity must be correct when the insulation resistance test is conducted.

The following minimum insulation values apply. The test voltages specified must be observed \*):

\*) These requirements comply with DIN VDE 0701-0702 and ÖVE/ÖNORM E8701-1. Also refer to the applicable requirements and standards in your country.


Measurement	Test voltage	Limit value
Primary -> ground	at least the max. DC input voltage of the device, however max. 1000 V	$\geq 1 \text{ M}\Omega$
Secondary -> ground	$\geq 500 \text{ V}$	$\geq 1 \text{ M}\Omega$

Legend: Primary = DC (DC+ and DC-) | Secondary = AC (L and N) | Ground = PE


The insulation resistance test must be conducted between the following points on both the inverter and the mounting bracket.

However, on the DC disconnect, the measurements should only be taken at the screws, not the contacts.


Ground to AC / Ground to DC




1 Measuring device  
2 Inverter  
9 Measuring line



Symo 10-20, Eco



Symo 10-20



Eco

Examples of measuring the insulation resistance.  
Overvoltage PC board (5)



**WARNING!** An electric shock can be fatal. Capacitors can charge during the insulation resistance measurement. After carrying out the insulation resistance test, check that all tested potentials are de-energised before continuing with the safety inspection. Alternatively, the capacitors can be discharged by short-circuiting the tested potentials or via the discharge function on the insulation tester.

Capacitor discharge time is at least 6 min.

### Ground conductor resistance


- Only perform the measurement if the insulation resistance test produced an acceptable result.
- Fit the cover back onto the inverter.
- Correct functioning of the ground conductor is only guaranteed if the results of the measurement between the cover and the mounting bracket are acceptable.
- The device being tested must be safely isolated from the AC grid (the grid lead [L, N] must not be connected). If the AC grid cannot be disconnected from the mounting bracket, the relevant safety precautions must be taken.
- Put the inverter back in the mounting bracket.



**CAUTION!** Take safety precautions. Observe the safety rules - DC voltage present!



**WARNING!** Set the inverter DC disconnecter to the 0 position and place the inverter in the mounting bracket. Placing the inverter in the mounting bracket causes a voltage to be applied to the inverter.



1 Measuring device  
2 Inverter  
9 Measuring line



Example: measuring the ground conductor resistance (A) - release on the power stage set cover

- Maybe you have to make a raw on the mounting bracket, that you get an electrical contact thru the oxide film or powder coating of the mounting bracket

- The resistance must not exceed 0.3  $\Omega$  \*)

\*) These requirements comply with DIN VDE 0701-0702 and ÖVE/ÖNORM E8701-1. Also refer to the applicable requirements and standards in your country.

## Ground conductor current

### Preparations

- Only perform the measurement if a ground conductor resistance test has been carried out successfully
- Direct method: The device must be isolated from earth. No other connections to the ground potential are permitted (e.g. data lines, fitting, etc.)
- Remove conductive objects from the housing
- Fit any missing housing parts



**WARNING!** An electric shock can be fatal. The inverter is live during the measurement.

Once the inverter has been connected, switch it back on. The inverter must be feeding energy during the measurement to avoid unreliable results.

Only the leakage currents that occur at grid frequency may be included (50 - 60 Hz function of ammeter). High-frequency leakage currents distort the measurement results \*).


\*) These requirements comply with DIN VDE 0701-0702 and ÖVE/ÖNORM E8701-1. Also refer to the applicable requirements and standards in your country.

There are two methods that may be used to measure the ground conductor current:

- Direct method: Device must be completely isolated and must not exhibit any links to another earth potential
- Differential current method

The measurement can be taken on the inverter (loop outside the device) or in the distributor. If taking the measurement in the distributor, ensure that there are no live conductors in the immediate vicinity and that no other consumers are connected to the same circuit.

**Direct method** - Ground conductor current measured using ammeter on the ground conductor




- 1 Measuring device
- 2 Inverter
- 8 Isolated setup of test piece
- 9 Measuring line




Examples of measuring the ground conductor current

**Differential current method** - Ground conductor current measured using an ammeter on the N and L conductors

As with an FI switch, the currents between the outer conductor (L) and the neutral conductor (N) are compared using a converter. The difference is displayed.



- 1 Measuring device
- 2 Inverter
- 9 Measuring line



Examples of measuring the ground conductor current

The ground conductor leakage current must not exceed 3.5 mA during this measurement (direct or differential current method \*\*).


\*\* ) These requirements comply with DIN VDE 0701-0702 and ÖVE/ÖNORM E8701-1. Also refer to the applicable requirements and standards in your country.

### Contact current

- Only perform the measurement if a ground conductor current measurement has been carried out successfully
- As before, the device must be switched on.

The measurement is taken between a grounded point and the touchable, conductive part that is not connected to the ground conductor.

The contact current must not exceed 0.5 mA \*).



- 1 Measuring device
- 2 Inverter
- 6.2 Touchable, conductive part not connected to the ground conductor
- 8 Isolated setup of test piece
- 9 Measuring line
- $R_i$  1 - 2 k $\Omega$

Touchable, conductive parts not connected to the ground conductor

\*) These requirements comply with DIN VDE 0701-0702 and ÖVE/ÖNORM E8701-1. Also refer to the applicable requirements and standards in your country.

# Finally...

---

## General

- Disconnect the inverter from the AC grid and DC supply when it is not under load (set the DC disconnect to position 0).
  - Re-attach/connect all the Datcom leads that were removed (restore the inverter to the state it was in before the repair or safety inspection).
  - If necessary, replace the AC lead in the PG gland.
  - Check whether any conductive objects have been placed in the housing.
  - Fit the Datcom cover with two 5x16 TX25 screws - **2 Nm**
- 

## General

- Any defects that could cause other hazards must be rectified immediately or restrictions placed on the further use of the system until repairs have been effected.
- Missing or damaged housing parts, insulation or protective covers.
  - Dirt or blockages in cooling openings.
  - Check that all safety-related labels (e.g. warning notices, grounding symbols, rating plates, etc.) are present. If required, replace, supplement or amend them as appropriate.
  - Ensure that all safety-related labels or symbols, measurement data and positioning indicators are legible.

# Function tests

---

**Function** Functions that the testing personnel consider to be relevant must be tested for correct operation.  
Energising and feeding-in of the inverter.

---

**Grid on/off devices** Evidence of proper operation must be provided by measurement or visual inspection.  
AC and DC main switch check (perform when under no or minimal load, but not in standby mode)

- Switch off DC main switch -> inverter must switch to error and stop feeding in energy
- Switch off AC main switch -> inverter switches off and display goes out
- Switch on AC main switch and DC main switch
- Perform a fan test - see operating instructions

---

**Indicators and control elements**

- Check display for correct function
- Check that controls work in line with the operating instructions

# Documentation

---

- Documentation**
- The electrician who performed the tests is responsible for compiling the proper documentation
  - Document all completed tests in a test record. Enter both the measured values and the equipment/calibration data used
  - If an individual test cannot be performed, the resulting decision must be justified and documented by the examiner
  - Any device that fails a test must be clearly marked as unsafe and the operator informed. The device may no longer be used.

The test record for the "Safety inspection" is available on the Fronius Partnerweb.



# Appendix

# Spare parts list: Fronius Symo


**Fronius Symo 10.0-3-M** 4,210,050  
**Fronius Symo 10.0-3-M light** 4,210,050,001  
**Fronius Symo 10.0-3-M Repl.** 4,210,050,001A  
**Fronius Symo 12.5-3-M** 4,210,051  
**Fronius Symo 12.5-3-M light** 4,210,051,001  
**Fronius Symo 12.5-3-M Repl.** 4,210,051,001A

42,0300,3054  
 40,0006,3231  
 42,0409,5194  
 40,0006,3070  
 44,0500,0047  
 42,0405,0992  
 4,071,334,Z  
 42,0405,0993  
 42,0201,4178  
 4,071,524,Z  
 42,0405,2094  
 42,0201,4179  
 BY2,0201,4919  
 42,0404,1379  
 42,0201,4177  
 4,240,038,Z  
 42,0405,2127,U  
 42,0405,1326  
 42,0401,4389  
 42,0401,1350  
 43,0004,5236  
 42,0201,4180  
 42,0405,2128  
 33,0010,0440 - 20kW\_1  
 33,0010,0447 - 20kW\_2  
 42,0201,7293  
 42,0405,2086  
 42,0201,4168  
 42,0401,4391  
 4,071,526A  
 4,071,526,Z  
 42,0201,4176  
 33,0010,0448  
 33,0010,0449 - FRT  
 42,0405,1107  
 42,0407,0802  
 43,0006,0280  
 42,0201,4175  
 42,0407,0790  
 42,0404,0391  
 42,0404,1378  
 42,0300,7310  
 41,0001,0708 Typ2  
 41,0001,0710  
 41,0001,0719 Typ1+2  
 42,0201,4276  
 43,0002,0489  
 42,0405,2096  
 42,0406,0368  
 42,0404,0452  
 42,0405,2089  
 42,0405,2088  
 DC- 42,0201,4480  
 DC+ 42,0201,4479  
 M16 42,0400,1035  
 M32 42,0407,0779  
 M16 42,0407,0756  
 M32 42,0407,0780  
 M32 42,0407,0682  
 42,0402,0298  
 43,0003,0812  
 43,0003,1451  
 43,0003,1115  
 43,0003,0992  
 43,0011,0059  
 42,0409,0253  
 42,0409,3626  
 42,0409,5163  
 42,0409,5212  
 TRANSPORT COVER ONLY  
 ← 2,5 Nm / 1.84 ft. lb. →

	M4x8	42,0401,0842
	M4x12	42,0401,1185
	M5x10	42,0401,0841
	M4x8	42,0401,1113
	M4x30	42,0401,1339
	M5x10	42,0401,1114
	M5x16	42,0401,1346
	M4x9	42,0401,1030
	M4x12	42,0407,0541
	Ø4mm	42,0407,0803
	15m4x3mm	42,0402,0311
	1/4"	42,0400,0400
	1/4"	42,0399,0187


Fronius Symo 10.0-3-M-OS  
 Fronius Symo 10.0-3-M-OS light  
 Fronius Symo 10.0-3-M-OS Repl.

4,210,050,200  
 4,210,050,201  
 4,210,050,201A




**Fronius Symo 15.0-3-M** 4,210,052  
**Fronius Symo 15.0-3-M light** 4,210,052,001  
**Fronius Symo 15.0-3-M Repl.** 4,210,052,001A  
**Fronius Symo 17.5-3-M** 4,210,053  
**Fronius Symo 17.5-3-M light** 4,210,053,001  
**Fronius Symo 17.5-3-M Repl.** 4,210,053,001A

**Fronius Symo 20.0-3-M** 4,210,054  
**Fronius Symo 20.0-3-M light** 4,210,054,001  
**Fronius Symo 20.0-3-M Repl.** 4,210,054,001A




# Spare parts list: Fronius Eco


- Fronius Eco 25.0-3-S 4,210,056,040
- Fronius Eco 25.0-3-S light 4,210,056,041
- Fronius Eco 25.0-3-S Repl. 4,210,056,041A
- Fronius Eco 27.0-3-S 4,210,057,040
- Fronius Eco 27.0-3-S light 4,210,057,041
- Fronius Eco 27.0-3-S Repl. 4,210,057,041A



# Circuit diagrams: Fronius Symo



# Circuit diagrams: Fronius Eco



# Fronius Worldwide - [www.fronius.com/addresses](http://www.fronius.com/addresses)

**Fronius International GmbH**  
4600 Wels, Froniusplatz 1, Austria  
E-Mail: [pv-sales@fronius.com](mailto:pv-sales@fronius.com)  
<http://www.fronius.com>

**Fronius USA LLC** Solar Electronics Division  
6797 Fronius Drive, Portage, IN 46368  
E-Mail: [pv-us@fronius.com](mailto:pv-us@fronius.com)  
<http://www.fronius-usa.com>

Under <http://www.fronius.com/addresses> you will find all addresses of our sales branches and partner firms!